

City Select Second Seat Kit Instructions





1 City Select Seat2 Adaptor Brackets



Adaptor Brackets

WARNING: Always remove child from seat before removing seat from frame.

The sample product shown on this manual may differ slightly from your production quality City Select Second Seat Kit. However, this will not affect the assembly or functionality of your Baby Jogger product.







- **1** From the front of, and facing the stroller, remove right front mounting bracket plug by firmly pressing the black button located above the front wheel and pulling up on the plug. Repeat on left side.
- 2 Insert right Adaptor Bracket into the right mounting bracket until it clicks into place. Repeat on left side.

NOTE: The Adaptor Brackets are labeled with an L or R for your convenience.





- **3** Align mounting brackets on the second seat with the top of the Adaptor Brackets.
- 4 Insert seat onto Adaptor Brackets until it clicks into place.

To Remove the City Select Second Seat:





- **1** Remove child from seat. Press grey buttons on seat mounting brackets and pull up until the seat detaches.
- **2** Press silver button on right Adaptor Bracket and pull upwards. Repeat on left side.

NOTE: Replace mounting bracket plugs when second seat is not in use.

NOTE: Your City Select Second Seat Kit can also be used facing the rear of the stroller.

When Rear Facing:



To make room for the seat's footwell: Unzip the right front and left front portions of the basket.



To adjust the footwell: Press both buttons on the side of the footwell and pull footwell upwards.

8575 Magellan Parkway, Suite 1000 • Richmond, VA 23227 T: 800-241-1848 • F: 804-262-6277 • www.babyjogger.com